


ICV & ICVD SERIES
REPLACEMENT PARTS FOR BOTH MODELS



ICV & ICVD SERIES - CONVECTION OVENS

ITEM NO	PART NO	DESCRIPTION
1	1126	POWER SWITCH - 3 POSITION, ON, OFF, & COOL DOWN
2	1127	FAN SWITCH (2 SPEED)
3	1128	MOMENTARY OVEN LIGHT SWITCH
4	1124	INDICATOR LIGHT
5	1162	BEZEL
6	1161	THERMOSTAT KNOB
7	1169	TIMER KNOB
8	1086	REGULAR CONTROL DECAL
9	22090	REGULAR CONTROL PANEL
10	1170	MANUAL TIMER
11	20275	THERMOSTAT BRACKET
12	1160	KXT THERMOSTAT - CONVECTION OVEN
13	1087	COMPUTER CONTROL DECAL
14	22089	COMPUTER CONTROL PANEL
15	1091	P. C. BOARD CONTROLLER
16	1134	SOLENOID VALVE
17	1133	FLAME SWITCH
18	1140	SPARK MODULE
19	1136	TERMINAL BLOCK
20	22097	R/H SIDE PANEL (FRONT)
21	22096 22296 22099 22299	R/H SIDE PANEL (REAR) R/H SIDE PANEL (REAR)-ICVD L/H SIDE PANEL (REAR) L/H SIDE PANEL (REAR)-ICVD
22	1050 1051	GAS PRESSURE REGULATOR 3/4" (NATURAL GAS) GAS PRESSURE REGULATOR 3/4" (PROPANE GAS)
23	1142	ELECTRICAL CORD
24	1904	5" BOLT
25	22080	FAN COVER
26	1166	SQUIRREL CAGE
27	1026	3" SPACER
28	1903	1-3/4" BOLT
29	22075	MOTOR MOUNTING PLATE ASSEMBLY
30	1902	SELF-RETAINING NUT
31	1025	1/2" SPACER
32	1164	OVEN MOTOR
33	22081	SNORKEL TUBE
34	22066	FLUE ASSEMBLY
35	1158	LIGHT BULB SOCKET
36	1157	LIGHT BULB
37	22130	LIGHT PROTECTOR
38	22040	HEAT DIVIDER (OVEN)
39	22050	FLUE EXTEND ASSEMBLY (DOUBLE STACK ONLY)
40	22121 22321	OUTER TOP COVER (ICV) OUTER TOP COVER (ICVD)
41	22120	TOP TRIM
42	22122	DOOR GASKET SIDE R/L
43	22123	DOOR GASKET TOP & BOTTOM

ITEM NO	PART NO	DESCRIPTION
44	22109	BIG DOOR ASSEMBLY
45	1860	GLASS DOOR WINDOW ASSEMBLY
46	22112	SMALL DOOR ASSEMBLY
47	22117	DOOR HANDLE ASSEMBLY
48	22119	VERTICAL DOOR SEAL
49	1840	BUSHINGS 5/8"
50	22100	LOWER HINGE BRACKET
51	23011	DOOR SUPPORT BRACKET
52	1155	DOOR SWITCH
	1355	DOOR SWITCH (PLUNGER STYLE)
53	1356	DOOR SWITCH ACTUATOR
54	22124	BURNER COMPARTMENT PANEL
55	22104	DOOR LOCK-IN BRACKET
56	1851	CHAIN LINKS
57	1852	SHORT ROD
58	1853	LONG ROD
59	1854	TURNBUCKLE
60	22093	MANIFOLD BRACKET
61	22098	GAS MANIFOLD PIPE (ICV)
	22294	GAS MANIFOLD PIPE (ICVD)
62	1701	ORIFICE ADAPTER
63	1700-36	OVEN ORIFICE (NATURAL)
	1700-50	OVEN ORIFICE (PROPANE)
64	22026	FRONT BAFFLE (ICV)
	22298	FRONT BAFFLE (ICVD)
65	22029	FRONT BAFFLE ENDS
66	22041	PILOT BRACKET BOTTOM
67	22042	PILOT BRACKET TOP
68	1097	OVEN PILOT BURNER W / IGNITION (NATURAL)
	1098	OVEN PILOT BURNER W / IGNITION (PROPANE)
	1058	#26 PILOT BELL ORIFICE ONLY - NATURAL GAS
	1059	#16 PILOT BELL ORIFICE ONLY - PROPANE GAS
69	1035	OVEN BURNER W / AIR SHUTTER (ICV)
70	1030	"U" BURNER ASSEMBLY W / AIR SHUTTER (ICVD)
71	2040	OVEN RACK (ICV)
	2042	OVEN RACK (ICVD)
72	2039	OVEN RACK GUIDE (ICV)
	2041	OVEN RACK GUIDE (ICVD)
73	20292	RACK GUIDE CLIPS
74	20131	27" LEG FOR AN ICV
75	23015	SPROCKET SHAFT
76	1045	ADJUSTABLE FOOT ONLY
77	1062	STEM CASTER
	1063	STEM CASTER WITH BRAKE
78	2502	CASTER (DOUBLE STACK ONLY)
	2503	CASTER WITH BARKE (DOUBLE STACK ONLY)
79	23016	KEY FOR SPROCKET SHAFT
80	23025	SPROCKET
81	22212	PROBE FOR COMPUTER CONTROL
82	22011	BOTTOM SHELF (ICV)
83	23029	ADJUSTABLE RACK SUPPORT